




T9500 LCM & LCM-P


Paging Staff Pagers (for units set for staff paging)

1. Enter the pager number
2. Press **MSG** button
 - MSG 1 lights pager indicator 1
 - MSG 2 lights pager indicator 2
 - MSG 3 lights pager indicator 3
 - MSG 4 lights pager indicator 4



Paging Guest Coasters and Paddles (for units set for guest paging)

1. Enter the pager number
2. Press **MSG** button
 - MSG 1 pages the coaster/pager to flash for 30-seconds
 - MSG 2 pages the coaster/pager to flash for 5-minutes
 - MSG 3 pages the coaster/pager to flash until reset
 - MSG 4 pages the coaster/pager into glow mode for 5-minutes



Page All Call (

If all guest and staff pagers need to be called at once, Press **0 0 0** then **MSG 1**

Changing Page functions

Function	LCM	LCM-p
Check Battery	8 Prog	Prog
Reset	000 Prog	000 Prog
Page Coasters	501 Prog	916 Prog
Page Paddles	501 Prog	918 Prog
Page Star Pagers	000 Prog	000 Prog or 917 Prog
Set Rest ID	900, 901, 902, 903	900, 901, 902, 903
Station ID	991, 992, 993	991, 992, 993
Range Test	912 Prog	912 Prog
Motor off	N/A	919 Prog
Motor on	N/A	920 Prog
Program pagers/coasters	N/A	<num> Prog
Mode (station vibe any message)	914 Prog	914 Prog
Mode (same vibe as message)	915 Prog	915 prog

