

TX-9550 LCK



One Touch Paging (Pagers 1 – 12)

Press the pager number

High number Paging (Pagers 13 – 899)

1. Press **PGR** button
2. Enter the pager number
3. Press **Enter**

Changing Page functions

Function	Press	Notes
Page All	PGR - 0 - 0 - 0 - ENT	Page all pagers not on charger
Check Battery	PROG - ENT	Nothing up to "3" Transmitter needs charging "5" indicates full charge
Reset	PROG - 0 - 0 - 0 - ENTER	
Set Restaurant ID	PROG - 9 - 0 - # - ENTER	# is ID Number from 0 to 5 (default = 0)
Station ID	PROG - 9 - 9 - # - ENTER	# is Station ID Number from 1 to 3
Range Test	PROG - 9 - 1 - 2 - ENTER	Vibrates once every 5 seconds
Set Vibe	PROG - 9 - 2 - 1 - ENTER PROG - 9 - 2 - 2 - ENTER PROG - 9 - 2 - 3 - ENTER	Will set the transmitter to 1 Vibration Will set the transmitter to 2 Vibrations Will set the transmitter to 3 Vibrations
Program pagers	PROG - # - PROG	# is pager number