



# Epson TM-T20III

## Integrierte USB-Schnittstelle aktivieren

### Betätigung der FEED-Taste:

KURZ = kurzer Tastendruck (kürzer als 1 Sekunde)

LANG = langer Tastendruck (länger als 1 Sekunde)

### Konfigurationsmodus einschalten

Führen Sie zunächst einen Selbsttest durch, indem Sie die FEED-Taste auf der Oberseite gedrückt halten und den Drucker einschalten. Die aktuelle Konfiguration wird ausgedruckt.

Drücken Sie nun die FEED-Taste **1x LANG**, um den Konfigurationsmodus zu aktivieren.

### Benutzerdefinierte Einstellungen

Wählen Sie nun die Option 3 (Customize Value Settings), indem Sie **3x KURZ** und zur Bestätigung **1x LANG** auf die FEED-Taste drücken.

### Interface Settings

Drücken Sie nun **2x KURZ** und **1x LANG** bis zum nächsten Ausdruck.

### Schnittstellen-Auswahl

Dann wählen Sie Option (Interface Selection), indem Sie **14x KURZ** und **1x LANG** auf die FEED-Taste drücken.

### Schnittstelle aktivieren

Um die integrierte USB-Schnittstelle zu aktivieren, wählen Sie hier die Option 2 (Build-in USB), indem Sie **2x KURZ** und zur Bestätigung **1x LANG** auf die FEED-Taste drücken.

FERTIG!



Mode Selection

Modes

0: Exit and Reboot Printer  
 1: NV Graphics Information  
 2: Receipt Enhancement Information  
 3: **Customize Value Settings**  
 4: Restore Default Values  
 5: Interface Setup  
 6: Peripheral Device Information  
 7 or more: None

Select Modes by executing following procedure.  
 step 1. Press the Feed button less than 1 second as many times as the selected mode number  
 step 2. Press the Feed button for 1 second or more

Customize Value Settings

Modes

0: Exit  
 1: Print Current Settings  
 2: **Interface Settings**  
 3: Print Density  
 4: Print Speed  
 5: Automatic Reduction of Paper  
 6: Auto Paper Feed&Cut at cover close  
 7: Character/Column Settings  
 8: Buzzer Control  
 9: near-end Detection  
 10: Power Supply Unit Capacity

Select Modes by executing following procedure.  
 step 1. Press the Feed button less than 1 second as many times as the selected mode number  
 step 2. Press the Feed button for 1 second or more

2. Interface Settings

Modes

0: Return to the previous menu  
 8: Receive Buffer Capacity  
 9: BUSY Condition  
 10: Auto Line Feed  
 11: State to cancel buffer BUSY  
 12: Output Paper-end Signals  
 13: Error Signal  
 14: **Interface Selection**

2. Interface Settings

2.14. Interface Selection

Modes

0: Return to the previous menu  
 2: **Built-in USB**  
 \*3: Ethernet  
 5: Auto

**EPSON**<sup>®</sup>  
 EXCEED YOUR VISION